

Produktinformation



Information



Tillverkare	Acer
Artnr	NP.BAG1A.189

Acer Traveler Case - Notebook carrying case - 15.6" - for Aspire 3; 5; Extensa 15; Nitro 5; Predator Helios 300; Predator Triton 300; 500

The Acer 15.6" Traveler Case is a functional solution for carrying your 15.6" notebook and accessories.

Specifikation

General

Product Type	Notebook carrying case
Notebook Compatibility	15.6"
Carrying Strap	Hand grip, shoulder carrying strap

Compatibility Information

Designed For	Acer Aspire 3 A315-23-A39D, A315-23-A6LJ, A315-23-A9KV, A315-23-R11P, A315-23-R1WB, A315-23-R2FW, A315-23-R52E, A315-23-R6U8, A315-23-R875, A315-23-R8AP, A315-23-R9A1, A315-34-C0V3, A315-34-P0T9, A315-34-P42N, A315-34-P4Q6, A315-34-P9PN, A315-42-R1DE, A315-42-R2DV, A315-42-R3DN, A315-42-R3QP, A315-42-R4FE, A315-42-R5P1, A315-42-R6HH, A315-42-R7HB, A315-42-R7HE, A315-42-R7ZX, A315-42-R9HX, A315-54K-30F9, A315-54K-32N4, A315-54K-35NE, A315-54K-38US, A315-54K-38X4, A315-55G-550F, A315-56-33CZ, A315-56-34PA, A315-56-35F5, A315-56-51SD, A315-56-5205, A315-56-56QM Acer Aspire 5 A515-44-R52A, A515-54-71FS, A515-54-71SK, A515-54-71ST, A515-55-500Y, A515-55-5135, A515-55-52NP, A515-55-59WM Acer Chromebook 11 C732-C073 Acer Chromebook 14 CB3-431-C5NV Acer Chromebook 15 CB3-532-C0Z8, CB515-1H-C019 Acer Chromebook 514 CB514-1H-C2WD Acer Chromebook 715 CB715-1WT-37GM, CB715-1WT-56SP, CB715-1WT-P9KU Acer Chromebook Spin 11 CP311-1H-C6E5, CP311-1HN-P2CZ, R751TN-C9KF Acer Chromebook Spin 13 CP713-1WN-31UU, CP713-1WN-5791, CP713-1WN-C4TJ Acer Extensa 15 EX215-51-55QK, EX215-51K-3267, EX215-51K-36TL, EX215-51K-380S, EX215-51K-38QT, EX215-51K-53MC, EX215-52-38YV, EX215-52-397U, EX215-52-517E Acer Nitro 5 AN515-44-R3SQ, AN515-44-R838, AN515-44-R9XE, AN515-54-56B8,
--------------	--

AN515-54-70TP, AN515-55-50MY, AN515-55-5933, AN515-55-59HN,
AN515-55-73G9, AN515-55-73LA, AN515-55-76BS Acer Predator
Helios 300 PH315-52-50F3, PH315-52-70EC, PH315-52-7166,
PH315-52-74W2, PH315-52-755M, PH315-52-75MC, PH315-52-79F3,
PH315-53-701Y, PH315-53-71E1, PH315-53-72AB, PH315-53-75QE,
PH315-53-76NL Acer Predator Triton 300 PT315-52-74EM Acer
Predator Triton 500 PT515-52-75XW Acer TravelMate P2410-
G2-M-53RQ, P2510-G2-M-54J0, P614-51-50AA, P614-51-51DT,
P614-51TG-52A6, TMP614-51-588N Acer TravelMate P2
TMP215-52-33GE, TMP215-52-50HY, TMP215-52-778D
Acer TravelMate X3 TMX3410-M-52M7 Acer TravelMate X5
TMX514-51-560Q, TMX514-51T-54EG