

Produktinformation



Information



Tillverkare Acer
Artnr NP.DCK11.01N

Acer USB Type-C Dock II - Docking station - USB-C - HDMI, DP - 135 Watt - Europe - for Swift 7; TravelMate P2510, P614, P648, TMP614; TravelMate P2; P6; X3; X5

Specifikation

General

Product Type	Docking station
Enclosure Colour	Black
Localisation	Europe

Expansion / Connectivity

Interfaces	2 x audio / video - HDMI 1 x audio / video - DisplayPort 1 x audio - headphones/microphone - mini-phone 3.5 mm 1 x network - Ethernet 1000 - RJ-45 1 x USB 3.1 Gen 1 with Battery Charging 1.2 2 x USB 3.1 Gen 1 1 x USB-C 1 x USB-C with Power Delivery
-------------------	--

Miscellaneous

Included Accessories	Stand
Features	Security lock slot (cable lock sold separately), wake on LAN, on/off switch, Preboot Execution Environment (PXE) support, MAC address pass-through
Security Slot Type	Kensington security slot
Compliant Standards	USB Battery Charging Specification Rev. 1.2, DisplayPort 1.2, USB Power Delivery 3.0

Power

Power Device	Power adapter
Power Provided	135 Watt

Compatibility Information

Designed For	Acer Chromebook 14 for Work CP5-471-30CJ, CP5-471-310R, CP5-471-31XB, CP5-471-32F1, CP5-471-37UK, CP5-471-37YG,
---------------------	---

CP5-471-39GM, CP5-471-39NU, CP5-471-57NQ, CP5-471-57UF,
CP5-471-C04K, CP5-471-C8FX Acer Chromebook 15 CB515-1H-
C7BN, CB515-1H-P0LA, CB515-1HT-P78M Acer Chromebook
Spin 11 R751T-C1QE, R751T-C1U9, R751T-C2KT, R751T-C68D,
R751T-C73B, R751T-C8A1, R751T-C8MB, R751TN-C25T Acer
Swift 5 SF514-52T-89AA Acer Swift 5 Pro SF514-52TP-50GX,
SF514-52TP-57FS, SF514-52TP-83QN Acer Swift 7 SF714-52T-733G
Acer Switch 5 SW512-52-557B, SW512-52-579B, SW512-52P-391C
Acer TravelMate P2410-M-39K4, P2410-M-P87C, P2410-M-P9ZA,
P2510-M-31DV, P2510-M-32UE, P2510-M-342F, P2510-M-388Q,
P2510-M-526D, P2510-M-5412, P2510-M-553Q, P2510-M-572F,
P2510-M-70MT, P2510-M-78DC, P449-M-527S, P449-M-72QZ,
P614-51-50AA, P614-51-51DT, P614-51TG-52A6, P648-G3-M-5007,
P648-G3-M-51TF, P648-G3-M-575U, P648-G3-M-58CT, P648-G3-
M-59LB, P648-G3-M-59R3, P648-G3-M-7132, P648-G3-M-777J, P658-
G3-M-54H3, P658-G3-M-55Y9, P658-G3-M-75UM, P658-M-51C2,
P658-M-51T7, P658-M-734N, TMP614-51-588N, X349-M-31KT Acer
TravelMate P2 TMP214-52-38MW, TMP214-52-53KG, TMP214-52-
P9WY, TMP215-52-33GE, TMP215-52-50HY, TMP215-52-778D Acer
TravelMate P6 TMP614-51-G2-55DK, TMP614-51-G2-7411 Acer
TravelMate X3 TMX314-51-M-37CZ, TMX314-51-M-77HR, TMX3410-
M-30Q6, TMX3410-M-31R3, TMX3410-M-32U2, TMX3410-M-33W6,
TMX3410-M-362K, TMX3410-M-501G, TMX3410-M-502N, TMX3410-
M-507D, TMX3410-M-51XY, TMX3410-M-52M7, TMX3410-M-53HY,
TMX3410-M-53Q7, TMX3410-M-54G3, TMX3410-M-5527, TMX3410-
M-558N, TMX3410-M-55NE, TMX3410-M-572F, TMX3410-M-57DD,
TMX3410-M-58MM, TMX3410-M-591R, TMX3410-M-59XB, TMX3410-
M-800J, TMX3410-M-809F, TMX3410-M-81DW, TMX3410-M-833H,
TMX3410-M-8357, TMX3410-M-83GD, TMX3410-M-8578, TMX3410-
M-85AU, TMX3410-M-87AK, TMX3410-M-88RF Acer TravelMate
X5 TMX514-51-560Q, TMX514-51-56RZ, TMX514-51-58CQ,
TMX514-51-7792, TMX514-51T-54EG, TMX514-51T-5998,
TMX514-51T-723A